





Step 8: Installing the door and lock

NO.	PART	Qty.
G3		1

















Lock failed




If the door gap is too wide and the lock fails, you can use the following methods to adjust.



FLOOR SUPPORT FRAME

NO.	PART	Qty.
W1	  1302mm	2
W2	  1339mm	2
W3	  716mm	3
ST4		8



SLOT INTO PLACE OR SCREW INTO FRAME.

