


# Metal Storage Box

## Instructions for Assembly

---



**PB02B: L132XW61XH62cm**

Requires two people and takes 1.5 hour for Installation.

Quick & Easy Assembly

Ridge Reinforced Walls

Available in Various Sizes

## BEFORE YOU START

### Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.


### Assembly instructions

Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin. During assembly, follow the step sequence carefully for correct results. Please be aware: **this unit takes two people about one full day to complete.**

### Parts


Check to be sure that you have all the necessary parts for the building. Separate contents of the carton by the part number while reviewing parts list. Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

## TOOLS MAY REQUIRED



**Use heavy duty gloves when handling steel sheets and flashing**

## PLAN AHEAD



### Watch the weather:

Please be sure the day you select for installation is dry and calm.

**DO NOT attempt to assemble your shed in windy weather** because of risk of damage to panels, or personal injury. Be careful of wet or muddy ground.

### Teamwork:

Whenever possible, two or more people should work together to assemble the building. One person can position parts or panels while the other is able to handle the fasteners and the tools.










## PLAN AHEAD







### Site Selection









- Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.
- Small trees, bushes or fences nearby can be helpful, acting as a wind break.


## IMPORTANT NOTES:


- Find someone to help you: it is much easier with someone to hold parts, pass tools ect. Also some steps require two people to lift structures together. This is not very heavy work so would suit most able-bodied people.
- Allow plenty of time: rushing often causes errors and the re-doing of incorrect assemblies. If you have never built a shed before, it can take most of a day to carefully complete the construction.
- Have the right tools to hand.
- Safety clothing as recommended in the 'Tools' section.
- Ideally lay out the parts and check that all are present before commencing construction. Lay on cloths or plastic sheets if there is any risk of scratching the parts.
- Tighten all nuts carefully, being sure not to miss any. Check the frame is square and using a spirit level to check that it is upright.

NO.	PART	Qty.
C1	 593mm	2
C2	 593mm	1
C3	 593mm	1
C4	 546mm	3
C5	 2	2
C8	 1	1
B1	 1	1
B2	 643mm	1
G3	 350X130-80N	2


NO.	PART	Qty.
PB02		1
P1	 560mm	1
P2	 560mm	1
P3	 1253mm	1
P4	 1253mm	1
P5	 1242mm	1

NO.	PART	Qty.
S4	 2	2
S5	 1	1
S6	 1	1
F1	 50	50
F2	 65	65
S3	 84	84
F8	 6	6
S8	 4	4






C1x1



C2x1



P1x1




F2 x 8





S3x8

Make sure all "ARROW" upward after assembling.



subassembly p1





P4x 1





F2 x 4



S3x4

subassembly p1







F2 x 4



S3x4

Make sure all "ARROW" upward after assembling.








C4 x 3



F1 x 12




x3






x6






P5x 1






C1x1



C3x1






P2x1




F2 x 8



S3x8



subassembly p2








F2 x 8



S3x8

Make sure all "ARROW" upward after assembling.






F1x 6



S3x6






F8x 4



S8x 4






S4x 2   S5x 1   S6x 1




F1x 16




S3x8







C8 x1





B1x1




F1x 2




Assembly the lock as shown





B2x1









PB02x1



F2 x 12







C5 x2



F1x6



G3 x 2





F2 x 8



S3x8

